

For enclosing vertical exhaust pipes to prevent rain water in the engine.

The raincap is balanced is suc a way that it will open when the engine starts and is closing when

the engine stops. The raincap is made out of high quality aluminum.

After assembly there is no need for maintenance on the cap anymore.

Pay attention: The dimensions are the outside dimensions of the exhaust pipe (not inner sizes)

Outside exhaust pipe = inside raincap.

A1	-	_	147 . 1 . 1 . 1	
Number	In mm	Туре	Weight	
0411460100	20	CCVC	100	
94H468100	29	66XS	190	
94H468101	32	66X	170	
94H468102	35	66	160	
94H468103	38	6	180	
94H468104	41	5XS	220	
94H468105	48	5	200	
94H468106	51	55	240	
94H468107	54	1	220	
94H468108	60	2	290	
94H468109	64	7	320	
94H468110	70	3	390	
94H468111	76	8	400	
94H468112	83	10	450	
94H468113	89	11	470	
94H468114	102	12	580	
94H468115	108	125	590	
94H468116	114	14	650	
94H468117	127	16	870	
94H468118	133	18	760	
94H468119	141	20	870	
94H468120	152	21	1070	
94H468121	168	22	1490	
94H468122	178	25	1500	
94H468123	210	27	2990	
94H468124	219	28	3070	
94H468125	254	30	3750	
94H468126	273	31	4500	
94H468127	305	32	7670	
94H468128	324	33	6930	
94H468129	356	34	7250	
94H468130	406	35	8220	





RVS Silentcap

Protects the engine with the only silent type of rain cap complete made out of stainless steel. Low noise, also at low motor load. Fully ballanced, sustainable maintenance free construction. Simple way to assemble.

Pay attention: The dimensions are the outside dimensions of the exhaust pipe (not inner sizes) Outside exhaust pipe = inside raincap.

Number	In mm
Nummer	In mm
94H468140	48
94H168141	60
94H168142	76
94H168143	89
94H168144	114
94H168145	140
94H168146	168
94H168147	219
94H168148	273

